



EN – USER'S MANUAL

Read the operating instructions carefully before use!
Save them for future reference!

Plastic Welder AMiO 04745

TECHNICAL SPECIFICATIONS

- Size: 225 × 155 mm
- Staple material: stainless steel
- Rated voltage: AC 230 V
- Output voltage: 0-3 V
- Rated power: 50 W
- Welder weight: 490 g

OPERATING INSTRUCTIONS

- Read this user manual in its entirety before using the product.
- The AMiO 04745 plastic welder is used to repair cracks in hard and thick plastic (thicker than 1.5 mm).
- Find the spot you wish to weld together and clean it.
- Identify what type of area it is. There are four different staples included in the package for different surfaces. See the picture below :



This type of staple is used for repairing outer corners.



This type of staple is used for repairing inner corners.



This type of staple is used for repairing thin cracks.



This type of staple is used for repairing wide and complex cracks.

- After you have chosen the most suitable staple for your repair, take the welder out of the box and plug it into an electrical outlet.
- Place the staple into the metal rods on the welder.
- Press and hold the trigger on the welder. This will heat the staple and make it glow red. The handy light on the welder will also illuminate the area you want to staple.
- Push the staple into the plastic and twist it a bit so that it can't be pulled out easily. Make sure that the piece you are repairing is held by a vice or similar tool – do not hold it in your hands while you are working.
- Stop holding the trigger and let the staple cool down a bit so that it stays inside the plastic.
- Remove the welder from the staple. At this point it should come off easily.
- Repeat this process as many times you need to complete your repair.
- After you're done welding, unplug the welder and let it cool down before storing it in the box.
- Take the included pliers and cut off any parts of the staples that are still sticking out of the plastic. We also recommend sanding the remains with sandpaper or a file for a smooth finish.

WARNINGS

- Wear safety gloves and goggles when using the tool.
- Make sure your work area is well lit and clean when using the product.

- Store out of children's reach.
- Do not modify the tool in any way.
- Do not touch the staples when the welder is working to prevent serious burns.
- Always wait for the welder to cool down before storing in the box.
- Do not under any circumstance use the gun on humans or animals.
- Do not use around flammable gasses and other substances.
- Do not use the product if it's damaged in any way.

DECLARATION OF CONFORMITY

Declaration of conformity available from AMiO Sp. z o.o.
ul. Handlowa 3, 41-807 Zabrze

ENVIRONMENTAL PROTECTION



This symbol indicates that this product should not be disposed of with unsorted municipal waste. Electronic equipment should not be disposed of with household waste. According to the European Directive 2002/96/EC on waste electrical and electronic equipment and its incorporation into national law, waste electrical and electronic equipment must be collected separately and recycled. You can also take your used equipment to an electronic waste collection point, which disposes of the equipment in accordance with the National Recycling and Waste Act. It also helps to avoid potential damage to the environment and human health and helps to conserve natural resources.

BG – РЪКОВОДСТВО ЗА УПОТРЕБА

(Превод на оригинална инструкция за употреба)

Прочетете внимателно инструкциите за употреба преди използване!
Запазете ги за бъдещи справки!
Уред за запояване на пластмаса със скоби AMiO 04745

ТЕХНИЧЕСКИ ХАРАКТЕРИСТИКИ

- Размери: 225 × 155 mm
- Материал на скобите: неръждаема стомана
- Номинално напрежение: AC 230 V
- Изходно напрежение: 0-3 V
- Номинална мощност: 50 W
- Тегло на уреда: 490 g

ИНСТРУКЦИИ ЗА УПОТРЕБА

- Прочетете изцяло това ръководство преди да използвате продукта.
- Заваръчният уред AMiO 04745 се използва за ремонт на пукнатини в твърда и дебела пластмаса (с дебелина над 1,5 mm).
- Намерете мястото, което желаете да ремонтирате, и го почистете.
- Определете вида на повърхността. В комплекта са включени четири различни вида скоби за различни приложения:



Този тип скоба се използва за ремонт на външни ъгли.



Този тип скоба се използва за ремонт на вътрешни ъгли.



Този тип скоба се използва за ремонт на тънки пукнатини.



Този тип скоба се използва за ремонт на широки и сложни пукнатини.

- Поставете скобата в металните държачи на уреда.
- Натиснете и задръжте спусъка. Скобата ще се нагрее и ще започне да свети в червено. Вградената светлина ще освети зоната на работа.
- Поставете скобата в пластмасата и леко я завъртете, за да не може лесно да бъде извадена. Уверете се, че детайлът е фиксиран в менгеме или подобен инструмент - не го дръжте в ръце по време на работа.
- Освободете спусъка и оставете скобата да се охлади леко, за да остане фиксирана в пластмасата.
- Отстранете уреда от скобата. Той трябва да се освободи лесно.
- Повторете процеса толкова пъти, колкото е необходимо за завършване на ремонта.
- След приключване изключете уреда от контакта и го оставете да се охлади преди да го приберете в кутията.
- С помощта на включените клещи отрежете стърчащите части на скобите. Препоръчва се също заглаждане със шкурка или пила за по-добър краен резултат.

ПРЕДУПРЕЖДЕНИЯ! ВНИМАНИЕ!

- Носете предпазни ръкавици и защитни очила по време на работа.
- Работете на добре осветено и чисто място.
- Съхранявайте извън обсега на деца.
- Не модифицирайте уреда по никакъв начин.
- Не докосвайте скобите по време на работа - съществува риск от сериозни изгаряния.
- Винаги изчакайте уредът да се охлади преди прибиране.
- При никакви обстоятелства не използвайте уреда върху хора или животни.
- Не използвайте в близост до запалими газове или вещества.
- Не използвайте продукта, ако е повреден.

ДЕКЛАРАЦИЯ ЗА СЪОТВЕТСТВИЕ

Декларация за съответствие може да бъде получена от:
AMiO Sp. z o.o.
ul. Handlowa 3, 41-807 Zabrze

ОПАЗВАНЕ НА ОКОЛНАТА СРЕДА



Този символ означава, че продуктът не трябва да се изхвърля с битовите отпадъци. Електронното оборудване не трябва да се изхвърля заедно с домакинските отпадъци. Съгласно Европейска директива 2002/96/ЕО относно отпадъците от електрическо и електронно оборудване и нейното прилагане в националното законодателство, отпадъците от електрическо и електронно оборудване трябва да се събират отделно и да се рециклират. Можете да предадете използваното оборудване в пункт за събиране на електронни отпадъци. Това спомага за предотвратяване на вреди за околната среда и човешкото здраве и за опазване на природните ресурси.